












Dell 27 Plus QHD USB-C-monitor

S2725DC


Snelstartgids












1





2








1





















1




2




3





Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/S2725DC